

# CONVOY PROCEDURE



# Overview and Objectives

The 57-Seater Buses and Line Haul Trucks travel in convoy. Convoys are used primarily for controlling movement of trucks and buses along the highway. A

A convoy procedure provides a guide on how convoy operates and also how other road users should do when approaching a convoy.

This presentation highlights the most important steps in the convoy procedure to ensure we;

- Avoid Incidents and
- Increase safety awareness



# General Information

The Line Haul Trucks are based in Tabubil and travel daily to Kiunga and return.

There are two convoys in a day, under 2 different Escort Vehicles.

First convoy leaves between 06:00am & 07:00am while 2<sup>nd</sup> convoy leaves Tabubil at 07:30am

Max number of trucks in each convoy can be 10, minimum 3, excluding Tyre Truck and Escort Vehicles. Increase safety awareness

Convoys arrives in Kiunga between 10am and 11am

1<sup>st</sup> Convoy departs Kiunga between 12:30pm and 1:00pm, 2<sup>nd</sup> convoy departs Kiunga between 1:00pm and 1:30pm and arrive Tabubil between 5 to 6pm.

A Tyre truck and a vehicle accompany the convoy.

Trucks that breaks down along the road are left on the side of the road with adequate warning signs. APD and Road Mechanics are notified



# General Information

The Escort/Convoy controller will display the appropriate number of trucks in the convoy and can easily be noticed with flashing lights and number display.

The maximum distance between the escort and the lead truck is 1 kilometer. Minimum distance is 500 meters.

Distance between truck to truck.

- Maximum distance 500metres
- Minimum distance 200metres

Convoy shall not give way to other traffic to pass except for emergency vehicles. i.e. police and ambulance.



# Warning Flags

- Each prime mover in a convoy will display **RED** flags
- Last Truck/Prime Mover in the convoy, normally displays **GREEN** flags Prime movers not in a convoy i.e. on local tasks (Mill/Mine/Town) runs, will not display flags.
- Trucks joining the main convoy i.e. from Bige or after break down contact convoy controller/escort leader and also display appropriate flags and Escort will also display appropriate flags and Escort will display appropriate number.



# Journey Management

## Road Intersections along the highway.

When at Road Junctions, convoy leader stops and wait until first truck is in view before continuing to prevent any traffic from entering between the trucks and the convoy escort.

## Road Intersections along the highway.

Escort vehicle park in the middle of the road with flashing lights stopping all oncoming traffic until all trucks have passed. When the last truck have passed, escort trucks leave allowing normal traffic flow



# Special Convoy Procedure

## Special convoys includes;

Travels alone. This is separate from the normal convoy. Transporting explosive containers or moving a wide or heavy load.

## Explosives

Trucks transporting explosives are usually escorted by police.

## Wide/Big Loads

- Wide/Big Loads may take a day or even several days to arrive in Tabubil and has its own Escort vehicle
- Notice / Safety Advice is usually sent out 24 hours before the movement.
- All drivers to take extra care when approaching special convoy.



# 57-Seater Bus Convoy

## General Procedure

- Maximum distance between the Escort & the Lead Bus is 1 Kilometre, Minimum distance is 500 metres.
- Maximum Distance bus to bus is 500, Minimum is 200 metres.
- Maximum number of 57 seaters in a convoy is ten.
- Convoy will be controlled by escort through radio contact with first and last buses.
- A convoy shall not give way to other traffic to pass the convoy; exception to emergency vehicles i.e. Police, Ambulance, Fire & Security.

## Warning Flags and Lights

- Escort vehicle displays **RED**, **GREEN**, **ORANGE** flashing lights & a board indicating number of buses in a convoy.
- Each 57 seater bus will display double blinking lights.
- Last bus on the convoy will display two **GREEN** flashing lights.
- Team Leader bus travels alone at a different timing displays two **GREEN** flashing lights and is escorted by a separate escort vehicle.





# Other Road Users

---

## What should other drivers do when approaching a convoy?

- When approaching a convoy, drive to a safe location and stop. Do not
- stop around blind corners.
- Do not overtake slow moving trucks travelling in a convoy
- Observe Escort Vehicle with board displaying number of buses / trucks in a convoy.
- Observe truck displaying green flag or bus with green flashing lights, which indicate convoy has passed and road free for traffic flow.
- Do not drive between convoys. If you see yourself driving between convoys, pull to a safe location and allow all the trucks before you proceed.